












BIG SHOT PARTS LIST



Part Number	Name	Picture
BS-01-003	Camera Board	
BS-01-004	Main I/O Board	
BS-01-005	Camera Display Board	
BS-01-006	Computer	
BS-01-007	Main Power Supply (12V)	
BS-01-008	LED Power Supply (5V)	
BS-01-010	Air Solenoid Valve	
BS-01-011-A	110 V Air Discharge Valve (For Compressor)	
BS-01-011-B	220 V Air Discharge Valve (For Compressor)	



BS-01-012	PC 12V power Adaptor	
BS-01-014-A	Triangle Button Assembly - Left	
BS-01-014-B	Triangle Button Assembly - Right	
BS-01-015	Round Button Assembly	
BS-01-016-C	Controller V2.0 and Silver Wire Harness Assembly	
BS-01-017	Controller Activation Microswitch	
BS-01-019-A	Controller Wire Harness - Black Casing	
BS-01-019-B	Controller Wire Harness - Silver Casing	
BS-01-020-B	Controller IR Cursor - Version 2	
BS-01-021	12V Cabinet Fan	
BS-01-023	Router	

BS-01-023-A	Router 12V Power Supply	
BS-01-024	EMI Filter	
BS-01-025	85" Monitor	
BS-01-033	110V Air Compressor	
BS-01-034	220V Air Compressor	
BS-01-043	110 Volt Air Compressor Start Capacitor	
BS-01-312	Sound System	
BS-01-312-B	Speakers (sold as pair)	
BS-01-360	Monitor Ribbon Cable - Logic Board to Screen Mesh	
BS-01-362	Monitor Ribbon Cable - 4K Board to Logic Board	
BS-01-370	Controller Harness to Camera Board Connection Harness	



BS-01-372	Wire Harness - Camera Board to I/O Board to to Player 1&2	
BS-01-422	Power Strip	
BS-01-425	Power Supply - LRS-200-12	
BS-01-428	Monitor Power Supply (HF240W-24)	
BS-01-437	Compressor Pressure Switch - 220 Volt	
BS-01-438	Compressor Pressure Switch - 110 Volt	
BS-01-1081	Ticket Signal Inverter Board	
BS-01-2104	Monitor Resolution Board	
BS-01-2110	Monitor Logic Board	
BS-01-2120	Monitor Converter Board	
BS-01-2130	Monitor Power Board	



BS-02-1010	Player Console LED Strip - Pink	
BS-02-1018	Controller Holder LED Strip - Blue	
BS-02-1020	Controller Holder LED Strip - Pink	
BS-02-1022	Between LED Strip - Blue	
BS-02-1024	Between LED Strip - Pink	
BS-02-1028	Monitor LED Strip - Pink	
BS-02-1030	Player Console LED – Floor – Front	
BS-03-010	Air Supply Collar - Male	
BS-03-011	Air Supply Collar - Female	
BS-03-012	Air / Water Separator	
BS-03-021	Activator Spring	



BS-03-022	Top Light Box (Marquee)	
BS-03-023	Top Light Box Metal Support	
BS-03-025	Controller Harness Mounting Block	
BS-03-025-S	Controller Mounting Block - Version 2 (for silver harness)	
BS-03-025-A	Controller Mounting Block Socket Cap Screw (M4x20)	
BS-03-026	Acrylic Monitor Protector	N/A
BS-03-027	Monitor Bracket	
BS-03-029	Player Console Acrylic	
BS-03-034	Air Hose - Sold by the foot	
BS-03-035	Hose Adjustment Connector	
BS-03-036	Hose to Hose Connector	





BS-03-100	Rotating Caster	
BS-03-101	Leg Leveler	
BS-03-202	Controller Shell Body & Top Slide - Version 1.3	
BS-03-202-B	Controller Shell Body & Top Slide - Version 2.0	
BS-03-205	Activator	
BS-03-206-A	Controller Tube (Controller IR Cursor Mount)	
BS-03-208	Sound Dispersement Device (Brass Threaded)	
BS-03-210	Adjustment Connector (Inside Controller)	
BS-03-211	Front Controller Body (Holds Tube)	
BS-03-212	Red Slide Stop	
BS-03-213	Cylinder Part 1 (Inside Firing Tube)	

BS-03-213-B	Cylinder Part 1 (Inside Firing Tube) - Version 2	
BS-03-214	Cylinder Part 2 (Outside Cylinder Block)	
BS-03-214-B	Cylinder Part 2 (Outside Cylinder Block) - Version 2	
BS-03-215	Return Spring	
BS-03-216	Top Slide & Slide Stop - Version 1.3	
BS-03-216-B	Top Slide & Slide Stop - Version 2.0	
BS-03-217	Controller Tube Screw - M10*1.5*10	
BS-03-218-B	Controller Front Head Screw	
BS-03-219	Controller Handle Screw - Right - M4x20 Cross Round Head	
BS-03-220	Top Slide Mid Screw - M3X10 Cross CS Head	
BS-03-221	Lock Washer - M3	

BS-03-221-B	Lock Washer - M4	
BS-03-222	Controller O-Ring - 12x1.5mm	
BS-03-224	Controller Activation Microswitch Mounting Screw - M2.5X10	
BS-03-225	Controller Tube Set Screw - M4X6	
BS-03-226	Controller Handle Screw - Left - M4x6 Cross Round Head	
BS-03-227	Controller Handle Butt Screw - Left - V1.1-V1.3 M3x6 Cross CS Head	
QS-03-228	Top Slide Butt/ Handle Butt-Right Screw - M3x16 Cross CS Head	
BS-03-229	Near Safety Screw - M3x10 Internal Hex Cup Head	
BS-03-230	Square Acrylic Mounting Screw - Hexhead M4x6	
BS-03-232	Compressor Bracket to Game Cabinet Screw - M8x25	
BS-03-233	Machine Screw - Connects Arm to the Monitor Console - M6X35 Stainless	

BS-03-234	Machine Screw - Connects Arm to Player Console - M6X12 Stainless	
BS-03-236	Handle Butt Screw - M4x30 Internal Hex. Cup Head (V2.0)	
BS-03-237	Lock Nut - M4	
BS-03-240	Controller V2.0 Tail Stock	
BS-03-241	Controller V2.0 Tail Stock Bushing	
BS-03-242	Controller V2.0 Tail Stock Bushing Screw - M4x6 Internal Hexhead	
BS-03-329	Controller Assembly Security Cable	
BS-03-360	Console Front Door	
BS-03-365	Top Slide Only - Version 1.3 (slide stop not included)	
BS-03-367	Top Slide Only - Version 2.0 (slide stop not included)	
BS-03-423	Controller Wire Cable Clip	

BS-03-450-A	Controller Hardware Kit - Version 1.1	
BS-03-450-B	Controller Hardware Kit - Version 1.2	
BS-03-450-C	Controller Hardware Kit - Version 1.3	
BS-03-450-D	Controller Hardware Kit - Version 2.0	
BS-03-459	Controller Mounting Block - Version 2 (for silver harness)	
BS-03-460	Silver Controller Harness Conversion Kit (can only be purchased w/ BS-01-019-B)	
BS-03-503	Aftermarket Monitor Conversion Bracket Kit	
BS-04-001	Door Key (HS888)	
BS-04-002	Door Lock (HS888)	
BS-04-1005	Acrylic Controller Holder - Left	
BS-04-1006	Acrylic Controller Holder - Right	

BS-04-1010	Player Console LED Acrylic - Upper - Left	
BS-04-1011	Player Console LED Acrylic - Upper - Right	
BS-04-1012	Player Console LED Acrylic - Upper - Top	
BS-04-1013	Player Console LED Acrylic - Upper - Bottom	
BS-04-1014	Player Console LED Acrylic - Floor - Left	
BS-04-1015	Player Console LED Acrylic - Floor - Right	
BS-04-1016	Player Console LED Acrylic - Floor - Front	
BS-04-1022	Between LED Acrylic - Pink - Left	
BS-04-1023	Between LED Acrylic - Pink - Right	
BS-04-1024	Between Blue LED Acrylic (Etched) - Left	
BS-04-1025	Between Blue LED Acrylic (Etched) - Right	

BS-04-1030	Monitor LED Acrylic - Left/Right	
BS-04-1031	Monitor LED Acrylic - Top/Bottom	
BS-06-110	Blue Border Screen Graphic	
BS-06-112	Controller Holder Graphic - Player 1	
BS-06-113	Controller Holder Graphic - Player 2	