









Captain Squiddy's Adventure Parts List

| <u>Part Number</u> | <u>Description</u> | <u>Picture of Part (If Available)</u> |
|--------------------|---------------------------------|--|
| CSA-01-0100 | Game Box - A25 |  |
| CSA-01-0103 | Settings Board |  |
| CSA-01-0105 | Hall Plate PCB |  |
| CSA-01-0112 | Power Supply - 12V 12A |  |
| CSA-01-0114 | Power Supply - 12V 17A |  |
| CSA-01-0123 | Motor - 12V90W |  |
| CSA-01-0125 | Turbine Gear Reduction Motor |  |
| CSA-01-0126 | DC Deceleration Motor |  |

CSA-01-0131 Motor Control Board



CSA-01-0135 Steering Wheel Assembly



CSA-01-0138 Speaker - 4 In.



CSA-01-0140 Upper Limit Position Detection Plate



CSA-01-0142 Flash LED Board



CSA-01-0144 "Lower Hook" Button



CSA-01-0150 Monitor - 17.3 Inch



CSA-01-0151 Monitor Driver Board - 17.3 inch



CSA-01-0152 LCD Cable - 17.3 inch



CSA-01-0155 Monitor - 23.6 Inch



CSA-01-0156

Monitor Driver Board -
23.6 inch



CSA-01-0157

Monitor Booster
Board - 23.6



CSA-01-0158

Monitor Booster
Board Cable - 23.6
Inch



CSA-01-0159

Monitor LCD Cable -
23.6 Inch



CSA-01-0160

Converter Board



CSA-01-0165

Monitor Assembly - 7
Inch



CSA-01-0166

Monitor - 7 Inch



CSA-01-0167

LCD Cable - 7 Inch



CSA-01-0168

Driver Board - 7 Inch



CSA-01-0169

Converter Board - 7
Inch



CSA-01-0183 Coin Mech



CSA-02-0215 Side LED Light



CSA-02-0217 Ceiling LED Board

CSA-03-0304 Joystick Assembly



CSA-03-0306 Joystick Handle



CSA-03-0310 Rotating Handle




CSA-03-0314 Interactive Fishing Assembly




CSA-03-0321 Boat Driver Game Contoller Assembly



CSA-04-0401 Header Acrylic



CSA-04-0402 Monitor Frame - 7 inch



CSA-04-0405

Dashboard



CSA-04-0411

Joystick Guard Acrylic



CSA-04-0412

Fishing Reel Acrylic
Side Cover



CSA-04-0415

Porthole Acrylic -
Blowfish




CSA-04-0416

Porthole Acrylic -
Clear

CSA-04-0418

Joystick Plexi Cover




CSA-04-0422

Celing Light Cover



CSA-04-0424

Speaker Cover



CSA-04-0428

Adjustable Game Foot



CSA-04-0429

Universal Wheel - 2.5
inches

