

Changing a JET Gun game credit status from coin to free play


Step # 1

Locate and press the Setup button of the Gun Game. This is normally located behind the coin access door. Please see 2 different examples of the setup button at the right.




Step # 2

Once inside the Setup menu of the Gun Game, you will see the attached picture to the right that shows the version of the software the game is running and you will be able to locate the Systems Menu option. To navigate this menu use the left and right arrows on the player console and use the "Start" button to enter or confirm the settings.



Step # 3


Once inside the "System Settings" menu select the "Basic" setting option



Changing a JET Gun game credit status from coin to free play


Step # 4

Once inside the "Basic Settings" menu you can select the credits required to play the game under "Coin Settings" or you can go down to the "FREE" menu option for Free Play (this is a setting which requires no coin input to play the game. "Start" button will automatically activate the game).



Step # 5

Highlight the "Free" option in the menu and click the "start" button on the console click the left or right button one to change the option in "Free" menu to "ON" as seen in the picture to the right. Then deselect the "Free" option menu.



Step # 6

After Deselection the "Free" option, you can then go to the bottom of the menu and select "Back" this will prompt a message "Some Settings Had Changed, Do You Want To Save It?" select "YES" if you want to save the changes you have made and then use the "Back" selection on the menus until you are back into game mode.

